

## Description

Pressure transducer without display and 1 pressure sensor.

PressureBox pressure transducer measure gauge, negative and differential pressure.

When PressureBox is entirely to be used as pressure transducer, the pressure is read from the analogue 0-10V / 4-20mA output. See below connection diagram.



## Warning




ESD Sensitive when lid is off. Make sure to be ESD discharged before touching the push-buttons.


## Mounting

Must be mounted on a non-vibrating surface in a non-condensing environment where not exposed to direct sunlight.

## Connection diagram



## Connecting Pressure tubes



Connecting pressure tubes to PressureBox with one transducer.

Pressure +  
Suction -

## Technical specifications

Supply Voltage:	24V AC/DC ±15%
Enclosure:	IP54
Dimension (HxWxD):	65x145x40mm
Pressure hose connection:	Ø 4mm
Humidity:	0-97%RH non-condensing
Working temperature:	
24VAC:	-20°C to +35°C
24VDC:	-20°C to +50°C
	non-condensing
Storage temperature:	+5°C to +50°C, non-condensing
Pressure area:	0-2500Pa (factory setting 0-500Pa)
Pressure accuracy:	See Manual
Output signal:	0-10V / 4-20mA

## Changing the pressure area for PressureBox

To change the pressure range of the transducer press button 1 so the yellow LED is constantly lit.

Press button 1 the number of times required to get the wanted pressure range.

- 1 time for 0-250Pa
- 2 times for 0-500Pa
- 3 times for 0-1500Pa
- 4 times for 0-2500Pa.

Press button 2 to save the selected pressure range. Also the selected setting is saved if no buttons are pushed for 10 seconds. Yellow LED turns off when selected pressure area is saved.

PressureBox is now ready to be used as pressure transducer where the pressure is read through the analogue output signal as 0-10V or 4-20mA signal.

The green LED will repeatedly flash the number of times corresponding to the selected pressure range.

If wrong pressure area has been chosen, the procedure needs to be repeated from the beginning.

Date: 01/09-2023  
 Drawn by: DF  
 Document No.: 950-208830 PressureBox E 2500 (0-500)\_ES 1088  
 Rev.: 1.2  
 Manufacturer: **LS Control A/S**, Industrivej 12, DK-4160 Herlufmagle



QR-kode for  
download af manual